
IN241200231V02_UK

B31-543V70





IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

ASSEMBLY INSTRUCTION

EN


Introduction

Thank you for purchasing our Floor Lamp. This lamp can be using as a reading lamp. Please read the following instructions carefully before use.

Parameter	
Model	B31-543V70(FLE-042-F2-C58-K1-ee-fff)
Input Voltage	100V-240V~50/60HZ
Material	Iron+PC
Dimmable	Yes
Switch	Remote control + Touch Control
Power	Max 42W
CCT	CCT 2700K-6500K


Cautions

1. If the remote control can't control the lamp, please try to match the codes. If you still can't control the lamp after the code is matched, please contact us as soon as possible.
2. Please make sure that the voltage is 100-240V, This product can only be used between100-240V.
3. Unplug before cleaning.



EN


Package List




A.Lampx1



B.Basex1



C. Power Adapter with Cable x 1



H.Remote Control x1


Assembling

Step 1: Connect the tube to the lamp head by clockwise.

Step 2: Connect the tube to the other tubes by clockwise.

Step 3: Finally connect the tube to the lamp base by clockwise. After the installation is finished, plug in adapter then you can touch control, or remote control the light.

Touch Control	
	Power: Short touch: Master Lamp ON/OFF Long touch: Sub-light ON/OFF
	Control master lamp: Short Press: Change the color temperature Long Press: Change the brightness
	Control sub-light : Short Press: Change the color temperature Long Press: Change the brightness



EN

Usage


on/off: ① Connect the power supply.

②Press switch button on the remote control.

③Press the " ⇄ " button to control the main-lamp or sub-lamp

CCT: Press the color temperature +/- button, short press is for grading dimming, long press is for stepless dimming.

Brightness: Press the brightness +/- button, short press is for grading dimming, long press is for stepless dimming.



Matching

Make sure the remote control matches well with the lamp:

Plug the adapter to the power supply and use the remote to control the lamp. Usually the remote controls the lamp perfectly.

If the remote control doesn't work for the lamp, please re-match them.


EN

Use Tips On Remote Control

- The remote control distance is within 49.2ft.
- The remote controller requires two AAA batteries.
- Pairing is not required before using.
- The back of the remote controller is magnetic and can be attached to a floor lamp pole or any other metal object.
- If the remote control fails to work, please re-pair the remote and lamp with the following methods:


1. Turn on the power switch;
2. Unplug the power cord 5 times in a row and reconnect it, the floor lamp will flash quickly about 3-5 seconds, and then you can Long press the "⏻" button (Main-Lamp) of the remote about 3 seconds within 1 minute until the light flickers twice, and then the remote has been successfully re-paired.

1




off-on-off-on-off-on-off-on-off-on

2



- If you want to cancel the pairing between the controller and the floor lamp. Please turn off-on-off-on-off-on-off-on-off-on the power, then the light flickers and the cancellation is completed.
- There is a magnet on the back of the remote controller, which can be adsorbed on any iron metalsurface such as floorlamp pole.



off-on-off-on-off-on-off-on-off-on

EN

Caution

- For indoor use only.
- Keep out of reach of children and animals.
- Do not use in the bathroom or damp places.
- Place the lamp on a flat surface and ensure it is placed away from any flammable materials.
- Before cleaning the lamp, ensure it is switched off.
- Before replacing the bulb, ensure the plug has been removed from the socket and the lamp has cooled down.
- Do not pull the plug out of the socket with wet hands.
- If the supply cord is damaged it must only be replaced by a qualified engineer.
- Do not touch light bulb while fixture is turned on.
- Never look directly at a lit bulb.
- **Notice: Do not repeatedly turning the light on and off.**

Care Instructions:

- Unplug lamp before cleaning.
- Wipe clean with a soft, dry cloth or static duster.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the fixture's finish.

If you have any questions, please contact our customer care center.
Our contact details are below:

0044-800-240-4004

enquiries@mhstar.co.uk

IMPORTER ADDRESS:
MH STAR UK Ltd
1 Northampton Cross Logistics Park
Northampton Cross Road
Northampton
NN4 9FH
MADE IN CHINA



FR

Cet appareil, ses accessoires, cordons et batteries se recyclent



Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

Aosom