Outsunny

IN251100145V01_UK

A20-634V70



CE

Outdoor Cas Stove

This product is a professional outdoor product, please read this instruction carefully before using.

INSTRUCTION MANUAL


Safety Warning

1. This product is used outdoors or in ventilated environment. It is strictly prohibited to use in tents, cars, rooms or other closed environments.
2. Avoid using in the hot sun or other high temperature environment.
3 Stop using immediately if gas leakage is found.
4. The structure of this product is precise, do not transform yourself, so as to avoid danger.
5. It is strictly prohibited to disassemble and install the gas tank when the fire is not extinguished, and it is strictly prohibited to disassemble and install the gas tank near the open fire.
6. Keep away from flammable and explosive materials when using.
7. Do not place the body (pay attention to the head and hands) above the stove when igniting, so as to avoid burns.
8.Children under 12 years old should not use this product alone.

Announcements

1. Please keep the stove dry, clean and avoid corrosion.
2. Discoloration of support and furnace surface is a normal phenomenon during use.
3. Keep the connection between valve body and tank clean to avoid airway blockage.
4. Use storage must be separated from the stove and gas tank after storage.
5. There will be a small amount of gas leakage during the installation and disassembly of the stove and gas tank. Do not install and disassemble in places with open flame or no air circulation.
6. When the stove is connected to the fuel with high pressure such as the liquefied gas tank, please pay attention to the control of the size of the fire, such as too much fire, and the contact with the pot is easy to cause the return flame phenomenon (the flame returns to the direct burning stove), resulting in the stove temperature is too high to burn the stove seal.

Product diagram



Basic parameters


Ignition method: External fire source
Fuel: liquefied gas, propane, butane gas
Combustion power :7000W
Material: stainless steel, aluminum alloy, et.

Gas Consumption:540g/h
Weight :750g
Unfold size :φ220*120mm
Fold size :φ140*95mm

Instructions

1. Connect the gas tank


1) Make sure the valve is closed (close the valve clockwise)
2) Connect the gas tank with the stove connector and tighten it.



Note: Before ignition, check whether there is gas leakage. If there is an odor (onion smell), please stop ignition immediately.

2. Light the burner

1) Expand and stabilize the upper and lower supports of the stove.
2) Use an external fire source to light (pay attention to the edge of the stove), and quickly withdraw your hand after lighting to avoid scalding.
3) Open the valve switch and ignite (do not open too much).




Attention: Do not place your head or other body parts over the stove while lighting. When connected with liquefied petroleum gas and other high pressure fuel, please pay attention to control the size of the fire, such as too much fire, and the pot after contact is easy to cause the flame phenomenon, resulting in the stove temperature is too high, easy to damage.

3. Turn off the stove

1) Turn off the valve switch, extinguish the flame, and leave it for 5 minutes to completely cool the stove.
2) Close the upper support and lower support of the stove.
3) Unscrew the stove connector from the gas tank and cover it Good dust cover.

Warning: Be sure to remove the gas cylinder before storage. Unscrew the stove and store the gas cylinder in a well-ventilated area.



UK

If you have any questions, please contact our customer care center.
Our contact details are below:



0044-800-240-4004



enquiries@mhstar.co.uk

IMPORTER ADDRESS:
MH STAR UK LTD
Unit 27, Perivale Park,
Horsenden lane South
Perivale, UB6 7RH
MADE IN CHINA

Aosom